

HOW TO MEASURE BODY IMPRESSIONS

1. Please remove all bedding before taking the measurements and pictures.
2. Place a long pole (like a broomstick) across the location of body impression(s). (Fig A)
3. Using a ruler, measure the depth of the body impression from the top of the mattress quilting (Fig. C) to the edge of yardstick and take 2 pictures that clearly show the measurement of the impression.

